

## **TIS connector pin layout**







Pin 5: ground I	Pin 4-1: RPM+ for 2, 4, 3, 1
5	
9	6
TIS socket (female)	Pin 9-6: RPM– for 2, 4, 3, 1

TIS channel	pin
A.0.1	1/6
A.0.2	4/9
A.0.3	2/7
A.0.4	3/8

RS422 differential input signals TTL-signal as twisted pair lines

20-01-13